

# 43iQ, 43iQHL, 43iQTL - 118207-00

## MODBUS Register Table

Rev AD  
V 01.06.17.35763

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
1	Auto Conc	float	0			Basic Units		Auto Concentration in Basic Units for logging/streaming (ppb or ug/m3)
7	Concentration (ppb or ug/m3)	float	0			Basic Units		Single/Low Range Concentration (ppb or ug/m3)
13	High Concentration (ppb or ug/m3)	float	0			Basic Units		High Range Concentration (ppb or ug/m3)
19	Auto Range Level	unsigned16	0	0	1			Indicates which Concentration is being used in Auto Range Mode 1 = high range 0 = low range
21	Instrument Temperature (Deg. C)	float	25			°C	1	Instrument Temperature (°C)
23	Bench Temperature (Deg. C)	float	45	-40	125	°C	1	Bench Temperature
31	Bench Pressure (mmHg)	float	750	500	1000	mmHg	1	Bench Pressure (mmHg)
33	Flow (L/min)	float	0	0	2	L/min	3	Flow (L/min)
35	PMT High Voltage (Volts)	float	-600	-1515.2	0	Volts	1	PMT Voltage
37	Flasher High Voltage (Volts)	float	800	0	1616.5	Volts	1	Lamp Voltage
39	Lamp Intensity	float	99	90	100	%	1	Lamp Intensity
81	SO2 Bkg (ppb)	float	0			PPB		SO2 Bkg (ppb)
501		string		6	9	characters		Formatted Time: HH:MM(:SS)
506		string		9	11	characters		Formatted Date: MM/DD/(YY)YY
512	Last Calibration Time	unsigned16	0			sec		Last Calibration Time (Seconds from 01-Jan-1970)
513	Previous Calibration Time	unsigned16	0			sec		Previous Calibration Time (Seconds from 01-Jan-1970)
514	General Alarm	unsigned32	1	0				General Alarm Flag
516	Instrument Serial Number	string	empty	0	14	characters		Serial Number
524	Firmware Version	string	empty	0	32	characters		Firmware Version
540		string	iQSeries	0	16	characters		HostName
548	Alerts	unsigned32	1	0				General Warning Flag
550	Instrument Warmup Enable	unsigned16	0	0	1			Instrument Warmup Flag set to 1 initially if warm up is enabled and either after all the module alarms are cleared up or after 2 hours set to 0
651	Pressure Alarm Status	unsigned16	1	0				Pressure Alarm Status
652	Flow Pressure Faults 3	unsigned16	0	0	65535			Pressure Faults 3: Bit7 - Board Communication Failure Bit14 - Power supplies Bit15 - General when any faults detected
653		unsigned16	0	0	65535			Pressure Cal Status 0 - Do nothing 1 - Reset all values to defaults 2 - Update high point sensor 13 - Update low point sensor 14 - Update high point sensor 25 - Update low point sensor 26 - Update high point sensor 37 - Update low point sensor 391 - Reset all values to defaults done 92 - Update high point sensor 1 done 93 - Update low point sensor 1 done 94 - Update high point sensor 2 done 95 - Update low point sensor 2 done 96 - Update high point sensor 3 done 97 - Update low point sensor 3 done

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
654	Flow Pressure Cal Faults 1	unsigned16	0	0	65535			Pressure Calibration Faults 1 (LSB): Bit 0-1: High point sensor 1 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit2-3: Low point sensor 1 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit4-5: High point sensor 2 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit6-7: Low point sensor 2 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit8-9: High point sensor 3 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit10-11: Low point sensor 3 Offset is: 00=Ok 01=user input out of range 10=measurement out of range 11=No calBit12-15=N/A
655	Flow/Pressure Communication Alarm	unsigned16	0	0	1			Flow/Pressure Communication Alarm Status
656	Flow/Pressure Power Supply Alarm	unsigned16	0	0	1			Flow/Pressure Power Supply Alarm Status
701	Perm Oven Gas Temp (Deg. C)	float				°C		Permeation Oven Gas Temperature (deg C) [if Perm Oven installed]
703	Perm Oven Body Temp (Deg. C)	float				°C		Permeation Oven Oven Body Temperature (deg C) [if Perm Oven installed]
705	Permeation Oven Alarms	unsigned16	1	0				Permeation Oven Alarms [if Perm Oven installed]
706	Perm Oven Oven Temperature Alarm Status	unsigned16	0	0	1			Perm Oven Oven Temperature Alarm Status [if Perm Oven installed]
707	Perm Oven Board Communication Alarm Status	unsigned16	0	0	1			Perm Oven Board Communication Alarm Status [if Perm Oven installed]
708	Perm Oven 5V Alarm Status	unsigned16	0	0	1			Perm Oven 5V Alarm Status [if Perm Oven installed]
709	Perm Oven 3.3V Alarm Status	unsigned16	0	0	1			Perm Oven 3.3V Alarm Status [if Perm Oven installed]
710	Perm Oven 3V Alarm Status	unsigned16	0	0	1			Perm Oven 3V Alarm Status [if Perm Oven installed]
711	Perm Oven 2.5V Alarm Status	unsigned16	0	0	1			Perm Oven 2.5V Alarm Status [if Perm Oven installed]
712	Perm Oven 24V Alarm Status	unsigned16	0	0	1			Perm Oven 24V Alarm Status [if Perm Oven installed]
713		unsigned16	0	0				Perm Oven Bit-packed faults 4: [if Perm Oven installed]Bit0 = UnusedBit1 = Heater status faultBit2 = heater power fault.Bit3 = 5 volts power fault.Bit 4 = 3.3 volts power fault.Bit5 = 2.5 volts power fault.Bit6 = 3 volts power fault.Bit7=Board communication failureBit8= Calibration fault.Bit9-13 = UnusedBit14 = Power supply failureBit 15 = Any faults in Fault 0 or and Fault 1
714		float	25			°C		Min Oven temperature [if Perm Oven installed]
716		float	105			°C		Max Oven temperature [if Perm Oven installed]
718	Perm Oven Body Thermistor Short	unsigned16	0	0	1			Perm Oven Body Thermistor Short Alarm Status [if Perm Oven installed]
719	Perm Oven Gas Thermistor Short	unsigned16	0	0	1			Perm Oven Gas Thermistor Short Alarm Status [if Perm Oven installed]
720	Perm Oven Body Thermistor Open	unsigned16	0	0	1			Perm Oven Body Thermistor Open Alarm Status [if Perm Oven installed]
721	Perm Oven Gas Thermistor Open	unsigned16	0	0	1			Perm Oven Gas Thermistor Short Alarm Status [if Perm Oven installed]
751	PSB Alarms	unsigned16	1	0				PSB Alarms Count

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
752	Faults 0	unsigned16	0	0	65535			Zero Gas Alicat's MFC Status Faults 0:Bit0 = Temperature Overflow(TOV)BIT1 = Temperature Underflow(TOV)BIT2 = Volumetric Overflow (VOV)BIT3 = Volumetric Underflow (VOV)BIT4 = Mass Overflow (MOV)Bit5 = Mass Underflow (MOV)Bit6 = Pressure Overflow (POV)Bit7 = Totalizer Overflow (OVR)Bit8 = PID Loop in Hold (HLD)Bit9 = ADC Error (ADC)Bit10= PID Exhaust (EXH)Bit11= Over Pressure Limit (OPL)Bit12= Flow Overflow during totalize (TMF)Bit13= Measurement was aborted
753	Faults 1	unsigned16	0	0	65535			Span Gas #1 Alicat's MFC Status Faults 1:Bit0 = Temperature Overflow(TOV)BIT1 = Temperature Underflow(TOV)BIT2 = Volumetric Overflow (VOV)BIT3 = Volumetric Underflow (VOV)BIT4 = Mass Overflow (MOV)Bit5 = Mass Underflow (MOV)Bit6 = Pressure Overflow (POV)Bit7 = Totalizer Overflow (OVR)Bit8 = PID Loop in Hold (HLD)Bit9 = ADC Error (ADC)Bit10= PID Exhaust (EXH)Bit11= Over Pressure Limit (OPL)Bit12= Flow Overflow during totalize (TMF)Bit13= Measurement was aborted
754	Faults 2	unsigned16	0	0	65535			Span Gas #2 (optional) Alicat's MFC StatusFaults 2:Bit0 = Temperature Overflow(TOV)BIT1 = Temperature Underflow(TOV)BIT2 = Volumetric Overflow (VOV)BIT3 = Volumetric Underflow (VOV)BIT4 = Mass Overflow (MOV)Bit5 = Mass Underflow (MOV)Bit6 = Pressure Overflow (POV)Bit7 = Totalizer Overflow (OVR)Bit8 = PID Loop in Hold (HLD)Bit9 = ADC Error (ADC)Bit10= PID Exhaust (EXH)Bit11= Over Pressure Limit (OPL)Bit12= Flow Overflow during totalize (TMF)Bit13= Measurement was aborted
755	Faults 3	unsigned16	0	0	65535			PSB Board most significant word Faults 3:Bit0..6=N/ABIT7=Board communication failureBIT8=Reset info block to defaultBIT9=Verify info block failBIT10=Reset calibration block to defaultBIT11=Verify calibration block failBit 12 - 13 = N/ABit14=Power Supply FailureBit15=General when any faults detected
756		unsigned16	0	0	65535			Status bits from STEP board 1:Bit Description0 Channel A 0=OK 1=Error (current>4A)1 Channel B 0=OK 1=Error (current>4A)2 Channel C 0=OK 1=Error (current>4A)3 Channel D 0=OK 1=Error (current>4A)4 Channel A 0=Off 1=On5 Channel B 0=Off 1=On6 Channel C 0=Off 1=On7 Channel D 0=Off 1=On8-11 5V Supply 0=Fail 0xa=Good12-15 24V Supply 0=Fail 0xa=Good
757		unsigned16	0	0	65535			Status bits from STEP board 2:Bit Description0 Channel A 0=OK 1=Error (current>4A)1 Channel B 0=OK 1=Error (current>4A)2 Channel C 0=OK 1=Error (current>4A)3 Channel D 0=OK 1=Error (current>4A)4 Channel A 0=Off 1=On5 Channel B 0=Off 1=On6 Channel C 0=Off 1=On7 Channel D 0=Off 1=On8-11 5V Supply 0=Fail 0xa=Good12-15 24V Supply 0=Fail 0xa=Good
758		unsigned16	0	0	65535			Status bits from STEP board 3:Bit Description0 Channel A 0=OK 1=Error (current>4A)1 Channel B 0=OK 1=Error (current>4A)2 Channel C 0=OK 1=Error (current>4A)3 Channel D 0=OK 1=Error (current>4A)4 Channel A 0=Off 1=On5 Channel B 0=Off 1=On6 Channel C 0=Off 1=On7 Channel D 0=Off 1=On8-11 5V Supply 0=Fail 0xa=Good12-15 24V Supply 0=Fail 0xa=Good
759		unsigned16	0	0	65535			Status bits from STEP board 4:Bit Description0 Channel A 0=OK 1=Error (current>4A)1 Channel B 0=OK 1=Error (current>4A)2 Channel C 0=OK 1=Error (current>4A)3 Channel D 0=OK 1=Error (current>4A)4 Channel A 0=Off 1=On5 Channel B 0=Off 1=On6 Channel C 0=Off 1=On7 Channel D 0=Off 1=On8-11 5V Supply 0=Fail 0xa=Good12-15 24V Supply 0=Fail 0xa=Good

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
760	PSB Communication Alarm	unsigned16	0	0	1			PSB Communication Status
761	PSB Power Supply Alarm	unsigned16	0	0	1			PSB Power Supply Status
762	STEP 1 Channel 1 Error	unsigned16	0	0	1			Channel 1 Error from STEP board
763	STEP 1 Channel 2 Error	unsigned16	0	0	1			Channel 2 Error from STEP board
764	STEP 1 Channel 3 Error	unsigned16	0	0	1			Channel 3 Error from STEP board
765	STEP 1 Channel 4 Error	unsigned16	0	0	1			Channel 4 Error from STEP board
766	STEP 1 5V Error	unsigned16	0	0	1			STEP 1 5V Error
767	STEP 1 24V Error	unsigned16	0	0	1			STEP 1 24V Error
768	STEP 2 Channel 1 Error	unsigned16	0	0	1			Channel 1 Error from STEP board
769	STEP 2 Channel 2 Error	unsigned16	0	0	1			Channel 2 Error from STEP board
770	STEP 2 Channel 3 Error	unsigned16	0	0	1			Channel 3 Error from STEP board
771	STEP 2 Channel 4 Error	unsigned16	0	0	1			Channel 4 Error from STEP board
772	STEP 2 5V Error	unsigned16	0	0	1			STEP 2 5V Error
773	STEP 2 24V Error	unsigned16	0	0	1			STEP 2 24V Error
774	STEP 3 Channel 1 Error	unsigned16	0	0	1			Channel 1 Error from STEP board
775	STEP 3 Channel 2 Error	unsigned16	0	0	1			Channel 2 Error from STEP board
776	STEP 3 Channel 3 Error	unsigned16	0	0	1			Channel 3 Error from STEP board
777	STEP 3 Channel 4 Error	unsigned16	0	0	1			Channel 4 Error from STEP board
778	STEP 3 5V Error	unsigned16	0	0	1			STEP 3 5V Error
779	STEP 3 24V Error	unsigned16	0	0	1			STEP 3 24V Error
780	STEP 4 Channel 1 Error	unsigned16	0	0	1			Channel 1 Error from STEP board
781	STEP 4 Channel 2 Error	unsigned16	0	0	1			Channel 2 Error from STEP board
782	STEP 4 Channel 3 Error	unsigned16	0	0	1			Channel 3 Error from STEP board
783	STEP 4 Channel 4 Error	unsigned16	0	0	1			Channel 4 Error from STEP board
784	STEP 4 5V Error	unsigned16	0	0	1			STEP 4 5V Error
785	STEP 4 24V Error	unsigned16	0	0	1			STEP 4 24V Error
801	Analog Input 1	float	0					Analog Input 1 Reading
803	Analog Input 2	float	0					Analog Input 2 Reading
805	Analog Input 3	float	0					Analog Input 3 Reading
807	Analog Input 4	float	0					Analog Input 4 Reading
809	Analog Alarms	unsigned16	1	0				Analog Alarms
810	Analog IO Faults 0	unsigned16	0	0	65535			Analog IO Faults 0: Bit-packed faults:Bit0 = 15V Status Diagnostic Failed Bit1 = Negative 15V Status Diagnostic Failed Bit2 = 5V Status Diagnostic Failed Bit3 = 3.3V Status Diagnostic Failed Bit4 = 5V Reference Status Diagnostic Failed Bit5..15 = N/A

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
811	Analog IO Faults 2	unsigned16	0	0	65535			Analog IO Faults 2: Bit-packed faults:Bit0 = Voltage Output Channel 1 Failed Bit1 = Voltage Output Channel 2 Failed Bit2 = Voltage Output Channel 3 Failed Bit3 = Voltage Output Channel 4 Failed Bit4 = Voltage Output Channel 5 Failed Bit5 = Voltage Output Channel 6 Failed Bit6 = Current Output Channel 1 Failed Bit7 = Current Output Channel 2 Failed Bit8 = Current Output Channel 3 Failed Bit9 = Current Output Channel 4 Failed Bit10 = Current Output Channel 5 Failed Bit11 = Current Output Channel 6 Failed Bit12 = AD5755 Temperature Too HighBit13 = AD5755-1 SPI Communications AlertBit14 = AD5755-2 SPI Communications Alert Bit15 = AD5755-3 SPI Communications Alert
812	Analog IO Faults 3	unsigned16	0	0	65535			Analog IO Faults 3: Bit-packed faults:Bit0..6 = N/ABit7 = Board Communication FailureBit8 = Information block set defaultBit9 = Information block corruptedBit10 = Calibration block set defaultBit11 = Calibration block corruptedBit12..13 = N/ABit14 = Power Supply FailureBit15 = General when any faults detected
813		unsigned16	0	0	65535			Analog IO Calibration Status: 0 = Calibration IdleVoltage Input Calibration 1 = Calculate voltage input start2 = Calculate voltage input stop3 = Calculate voltage input default4 = Calibration voltage input done Voltage Output Calibration 5 = Calculate voltage output start6 = Calculate voltage output stop7 = Calculate voltage output default8 = Calibration voltage output done Current Output Calibration 9 = Calculate current output start10 = Calculate current output stop11 = Calculate current output default12 = Calibration voltage output done
814	Analog IO Cal Faults 1	unsigned16	0	0	65535			Analog IO Cal Faults 1: Bit-packed faults for voltage input calibration:Bit0-1 = Channel 1 voltage input calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit2-3 = Channel 2 voltage input calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit4-5 = Channel 3 voltage input calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit6-7 = Channel 4 voltage input calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit8..15 = N/A
815	Analog IO Cal Faults 2	unsigned16	0	0	65535			Analog IO Cal Faults 2: Bit-packed faults for voltage output 5V range calibration:Bit0-1 = Channel 1 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit2-3 = Channel 2 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit4-5 = Channel 3 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit6-7 = Channel 4 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit8-9 = Channel 5 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit10-11 = Channel 6 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit12..15=N/A
816	Analog IO Cal Faults 3	unsigned16	0	0	65535			Analog IO Cal Faults 3: Bit-packed faults for voltage output 10V range calibration:Bit0-1 = Channel 1 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit2-3 = Channel 2 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit4-5 = Channel 3 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit6-7 = Channel 4 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit8-9 = Channel 5 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit10-11 = Channel 6 voltage output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit12..15=N/A

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
817	Analog IO Cal Faults 4	unsigned16	0	0	65535			Analog IO Cal Faults 4: Bit-packed faults for current output calibration:Bit0-1= Channel 1 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit2-3= Channel 2 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit4-5= Channel 3 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit6-7= Channel 4 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit8-9= Channel 5 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit10-11= Channel 6 current output calibration failureOffset is: 00 = Ok 01 = Low 10 = High 11 = No calBit12..15=N/A
818	Analog IO Voltage Output Channel 1 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 1 Alarm Status
819	Analog IO Voltage Output Channel 2 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 2 Alarm Status
820	Analog IO Voltage Output Channel 3 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 3 Alarm Status
821	Analog IO Voltage Output Channel 4 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 4 Alarm Status
822	Analog IO Voltage Output Channel 5 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 5 Alarm Status
823	Analog IO Voltage Output Channel 6 Alarm	unsigned16	0	0	1			Analog IO Voltage Output Channel 6 Alarm Status
824	Analog IO Current Output Channel 1 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 1 Alarm Status
825	Analog IO Current Output Channel 2 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 2 Alarm Status
826	Analog IO Current Output Channel 3 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 3 Alarm Status
827	Analog IO Current Output Channel 4 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 4 Alarm Status
828	Analog IO Current Output Channel 5 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 5 Alarm Status
829	Analog IO Current Output Channel 6 Alarm	unsigned16	0	0	1			Analog IO Current Output Channel 6 Alarm Status
830	Analog IO Chip Temperatures Alarm	unsigned16	0	0	1			Analog IO Chip Temperatures Alarm Status
831	Analog IO Chip 1 Communication Alarm	unsigned16	0	0	1			Analog IO Chip 1 Communication Alarm Status
832	Analog IO Chip 2 Communication Alarm	unsigned16	0	0	1			Analog IO Chip 2 Communication Alarm Status
833	Analog IO Chip 3 Communication Alarm	unsigned16	0	0	1			Analog IO Chip 3 Communication Alarm Status
834	Analog IO Communication Alarm	unsigned16	0	0	1			Analog IO Communication Alarm Status
835	Analog IO Power Supply Alarm	unsigned16	0	0	1			Analog IO Power Supply Alarm Status
851	Bench Alarm Count	unsigned16	1	0				Bench Alarm Count
852	Flash Ref Pct Alarm Status	unsigned16	0	0	1			Flash Reference Percent Alarm Status

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
853	Adc Flash HV Alarm Status	unsigned16	0	0	1			Lamp Voltage Alarm Status
854	Bench Communication Alarm	unsigned16	0	0	1			Communication Alarm Status
855	Bench Power Supply Alarm	unsigned16	0	0	1			Power Supply Alarm Status
856	Bench Temperature Alarm	unsigned16	0	0	1			Bench Temp Alarm Status
857	Bench Low Voltage Alarm	unsigned16	0	0	1			Bench Supply Lo Alarm Status
858	Bench High Voltage Alarm	unsigned16	0	0	1			Bench Supply Hi Alarm Status
902	Concentration Alarms	unsigned16	0	0	1			Conc/AutoZero/AutoSpan Alarms
903	SO2 Concentration Alarm	unsigned16	0	0	1			Concentration Alarm Status
904	Bench Pressure Alarm	unsigned16	0	0	1			Bench Pressure Alarm Status
905	Flow Alarm	unsigned16	0	0	1			Flow Alarm Status
906	Temperature Alarm	unsigned16	0	0	1			Instrument Temperature Alarm Status
907	Auto Zero Cal/Check Alarm	unsigned16	0	0	1			Auto Zero Cal/Check Alarm Status
908	Auto Span Cal/Check Alarm	unsigned16	0	0	1			Auto Span Cal/Check Alarm Status
909		string	0	0	11			Single/Low Range Concentration String in User Defined Units
915		string	0	0	11			Hi Range Concentration String in User Defined Units
921	Flow Pressure Module Alarms	unsigned16	0	0	1			Bench Module Alarms (also includes Flow - Bench Pressure and Instrument Temperature from the Flow/Pres Status and Alarms screen)
922	Pump Pressure (mmHg)	float		0	1000	mmHg	1	Pump Pressure (mmHg)
925		float	0			Basic Units		Low Range Virtual Conc. for UI only
927		float	0			Basic Units		Hi Range Virtual Conc. for UI only
929		float	1	0.5	2		3	Lo Range User Coef for Calculations
931		float	1	0.5	2		3	Hi Range User Coef for Calculations
933		float	0			Basic Units		Background
951	Digital IO Alarms	unsigned16	1	0				Digital IO Alarms
952	Digital IO Faults 0	unsigned16	0	0	65535			Digital IO Board fault register 1 least significant wordBit 0 = Solenoid1 above 500mA shut down and alarmBit 1 = Solenoid1 below 10mA and output is onBit 2 = Solenoid2 above 500mA shut down and alarmBit 3 = Solenoid2 below 10mA and output is onBit 4 = Solenoid3 above 500mA shut down and alarmBit 5 = Solenoid3 below 10mA and output is onBit 6 = Solenoid4 above 500mA shut down and alarmBit 7 = Solenoid4 below 10mA and output is onBit 8 = Solenoid5 above 500mA shut down and alarmBit 9 = Solenoid5 below 10mA and output is onBit 10 = Solenoid6 above 500mA shut down and alarmBit 11 = Solenoid6 below 10mA and output is onBit 12 = Solenoid7 above 500mA shut down and alarmBit 13 = Solenoid7 below 10mA and output is onBit 14 = Solenoid8 above 500mA shut down and alarmBit 15 = Solenoid8 below 10mA and output is on
953	Digital IO Faults 1	unsigned16	0	0	65535			Digital IO Board fault register 2
954	Digital IO Faults 3	unsigned16	0	0	65535			Digital IO Board fault register 4 most significant wordBit0..9= N/A Bit 7 = Board Communication FailureBit8 = Information block set defaultBit9 = Information block corruptedBit10 = Calibration block set defaultBit11 = Calibration block corruptedBit12..13 = N/ABit14 = Power Supply Bit15 = General when any faults detected



Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
955	External Alarm 1	unsigned16	0	0	1			Digital IO External Alarm 1
956	External Alarm 2	unsigned16	0	0	1			Digital IO External Alarm 2
957	External Alarm 3	unsigned16	0	0	1			Digital IO External Alarm 3
958	Digital IO Fault Reset	unsigned16	0	0	255			Reset the solenoid faults Bit0 = 24V Switchable Output 0 Bit1 = 24V Switchable Output 1 Bit2 = 24V Switchable Output 2 Bit3 = 24V Switchable Output 3 Bit4 = 24V Switchable Output 4 Bit5 = 24V Switchable Output 5 Bit6 = 24V Switchable Output 6 Bit7 = 24V Switchable Output 7 Bit8..15 = N/A
959	Digital IO Solenoid1 High Alarm	unsigned16		0	1			Digital I/O solenoid1 above 500mA alarm
960	Digital IO Solenoid1 Low Alarm	unsigned16		0	1			Digital I/O solenoid1 below 10mA alarm
961	Digital IO Solenoid2 High Alarm	unsigned16		0	1			Digital I/O solenoid2 above 500mA alarm
962	Digital IO Solenoid2 Low Alarm	unsigned16		0	1			Digital I/O solenoid2 below 10mA alarm
963	Digital IO Solenoid3 High Alarm	unsigned16		0	1			Digital I/O solenoid3 above 500mA alarm
964	Digital IO Solenoid3 Low Alarm	unsigned16		0	1			Digital I/O solenoid3 below 10mA alarm
965	Digital IO Solenoid4 High Alarm	unsigned16		0	1			Digital I/O solenoid4 above 500mA alarm
966	Digital IO Solenoid4 Low Alarm	unsigned16		0	1			Digital I/O solenoid4 below 10mA alarm
967	Digital IO Solenoid5 High Alarm	unsigned16		0	1			Digital I/O solenoid5 above 500mA alarm
968	Digital IO Solenoid5 Low Alarm	unsigned16		0	1			Digital I/O solenoid5 below 10mA alarm
969	Digital IO Solenoid6 High Alarm	unsigned16		0	1			Digital I/O solenoid6 above 500mA alarm
970	Digital IO Solenoid6 Low Alarm	unsigned16		0	1			Digital I/O solenoid6 below 10mA alarm
971	Digital IO Solenoid7 High Alarm	unsigned16		0	1			Digital I/O solenoid7 above 500mA alarm
972	Digital IO Solenoid7 Low Alarm	unsigned16		0	1			Digital I/O solenoid7 below 10mA alarm
973	Digital IO Solenoid8 High Alarm	unsigned16		0	1			Digital I/O solenoid8 above 500mA alarm
974	Digital IO Solenoid8 Low Alarm	unsigned16		0	1			Digital I/O solenoid8 below 10mA alarm
975	Digital IO Power Supply Alarm	unsigned16		0	1			Digital I/O power supply alarm
976	Digital IO Communication Alarm	unsigned16	0	0	1			Digital IO Communication Alarm
977		unsigned16	0	0	1			Digital IO Relay Test Mode Alarm
978		unsigned16	0	0	1			Digital IO Solenoid Test Mode Alarm
1001		integer16	0	-99	60			Maintenance History Calculated Months Left Optical Bench Module
1002		integer16	0	-99	60			Maintenance History Calculated Months Left UV Lamp
1003		integer16	0	-99	60			Maintenance History Calculated Months Left PMT



Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
1004		integer16	0	-99	60			Maintenance History Calculated Months Left PMT Base Socket
1005		integer16	0	-99	60			Maintenance History Calculated Months Left Flash Intensity Assy
1006		integer16	0	-99	60			Maintenance History Calculated Months Left Mirrors
1007		integer16	0	-99	60			Maintenance History Calculated Months Left Flow System
1008		integer16	0	-99	60			Maintenance History Calculated Months Left Capillaries
1009		integer16	0	-99	60			Maintenance History Calculated Months Left Pump
1010		integer16	0	-99	60			Maintenance History Calculated Months Left DC Power Supply
1011		integer16	0	-99	60			Maintenance History Calculated Months Left Foam Fan Filter
1012		integer16	0	-99	60			Maintenance History Calculated Months Left System Components
1013		integer16	0	-99	60			Maintenance History Calculated Months Left Purafil
1014		integer16	0	-99	60			Maintenance History Calculated Months Left Charcoal
1015		integer16	0	-99	60			Maintenance History Calculated Months Left Dri-Rite
1016		integer16	0	-99	60			Maintenance History Calculated Months Left Permeation Tube
1017		integer16	0	-99	60			Maintenance History Calculated Months Left 17
1018		integer16	0	-99	60			Maintenance History Calculated Months Left 18
1019		integer16	0	-99	60			Maintenance History Calculated Months Left 19
1020		integer16	0	-99	60			Maintenance History Calculated Months Left 20
1021		integer16	0	-99	60			Maintenance History Calculated Months Left 21
1022		integer16	0	-99	60			Maintenance History Calculated Months Left 22
1023		integer16	0	-99	60			Maintenance History Calculated Months Left 23
1024		integer16	0	-99	60			Maintenance History Calculated Months Left 24
1025		integer16	0	-99	60			Maintenance History Calculated Months Left 25
1026		integer16	0	-99	60			Maintenance History Calculated Months Left 26
1027		integer16	0	-99	60			Maintenance History Calculated Months Left 27
1028		integer16	0	-99	60			Maintenance History Calculated Months Left 28
1029		integer16	0	-99	60			Maintenance History Calculated Months Left 29
1030		integer16	0	-99	60			Maintenance History Calculated Months Left 30
1031		integer16	0	-99	60			Maintenance History Calculated Months Left 31
1032		integer16	0	-99	60			Maintenance History Calculated Months Left 32
1033		integer16	0	-99	60			Maintenance History Calculated Months Left 33
1034		integer16	0	-99	60			Maintenance History Calculated Months Left 34
1035		integer16	0	-99	60			Maintenance History Calculated Months Left 35
1036		integer16	0	-99	60			Maintenance History Calculated Months Left 36
1037		integer16	0	-99	60			Maintenance History Calculated Months Left 37
1038		integer16	0	-99	60			Maintenance History Calculated Months Left 38
1039		integer16	0	-99	60			Maintenance History Calculated Months Left 39
1040		integer16	0	-99	60			Maintenance History Calculated Months Left 40
1041		integer16	0	-99	60			Maintenance History Calculated Months Left 41
1042		integer16	0	-99	60			Maintenance History Calculated Months Left 42
1043		integer16	0	-99	60			Maintenance History Calculated Months Left 43
1044		integer16	0	-99	60			Maintenance History Calculated Months Left 44
1045		integer16	0	-99	60			Maintenance History Calculated Months Left 45
1046		integer16	0	-99	60			Maintenance History Calculated Months Left 46
1047		integer16	0	-99	60			Maintenance History Calculated Months Left 47
1048		integer16	0	-99	60			Maintenance History Calculated Months Left 48
1049		integer16	0	-99	60			Maintenance History Calculated Months Left 49
1050		integer16	0	-99	60			Maintenance History Calculated Months Left 50
1051	Maintenance History Alert	unsigned16	0	0	1			Maintenance History Alert
1101	Predictive Diagnostics Alerts List	string		0	300			Predictive Diagnostics Alerts List

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
1301	Predictive Diagnostic Alert 1	unsigned16	0	0	1			Predictive Diagnostic Alert Sample Pump
1302	Predictive Diagnostic Alert 2	unsigned16	0	0	1			Predictive Diagnostic Alert Capillary
1303	Predictive Diagnostic Alert 3	unsigned16	0	0	1			Predictive Diagnostic Alert Flow Path
1304	Predictive Diagnostic Alert 4	unsigned16	0	0	1			Predictive Diagnostic Alert Sample Valve
1305	Predictive Diagnostic Alert 5	unsigned16	0	0	1			Predictive Diagnostic Alert Zero Valve
1306	Predictive Diagnostic Alert 6	unsigned16	0	0	1			Predictive Diagnostic Alert Span Valve
1307	Predictive Diagnostic Alert 7	unsigned16	0	0	1			Predictive Diagnostic Alert 7
1308	Predictive Diagnostic Alert 8	unsigned16	0	0	1			Predictive Diagnostic Alert 8
1309	Predictive Diagnostic Alert 9	unsigned16	0	0	1			Predictive Diagnostic Alert 9
1310	Predictive Diagnostic Alert 10	unsigned16	0	0	1			Predictive Diagnostic Alert 10
1311	Predictive Diagnostic Alert 11	unsigned16	0	0	1			Predictive Diagnostic Alert 11
1312	Predictive Diagnostic Alert 12	unsigned16	0	0	1			Predictive Diagnostic Alert 12
1313	Predictive Diagnostic Alert 13	unsigned16	0	0	1			Predictive Diagnostic Alert 13
1314	Predictive Diagnostic Alert 14	unsigned16	0	0	1			Predictive Diagnostic Alert 14
1315	Predictive Diagnostic Alert 15	unsigned16	0	0	1			Predictive Diagnostic Alert 15
1316	Predictive Diagnostic Alert 16	unsigned16	0	0	1			Predictive Diagnostic Alert 16
1317	Predictive Diagnostic Alert 17	unsigned16	0	0	1			Predictive Diagnostic Alert 17
1318	Predictive Diagnostic Alert 18	unsigned16	0	0	1			Predictive Diagnostic Alert 18
1319	Predictive Diagnostic Alert 19	unsigned16	0	0	1			Predictive Diagnostic Alert 19
1320	Predictive Diagnostic Alert 20	unsigned16	0	0	1			Predictive Diagnostic Alert 20
1321	Predictive Diagnostic Alerts	unsigned16	0	0	1			Predictive Diagnostic Alerts
2251	Zero/Span Enable	unsigned16	0	0	1			Enable/Disable the Zero/Span valve module
2252		unsigned16	0	0	1			Trigger zero check or cal.
2253		unsigned16	0	0	1			Trigger span check or cal.
2254		unsigned16	0	0	1			Trigger purge
2255		unsigned16	0	0	1			Status of Ozonator Level 1 (0=Off; 1=On)
2256		unsigned16	0	0	1			Status of Ozonator Level 2 (0=Off; 1=On)
2257		unsigned16	0	0	1			Status of Ozonator Level 3 (0=Off; 1=On)

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
2258		unsigned16	0	0	1			Status of Ozonator Level 4 (0=Off; 1=On)
2259		unsigned16	0	0	1			Status of Ozonator Level 5 (0=Off; 1=On)
2260		unsigned16	0	0	1			Status of Ozonator Level 6 (0=Off; 1=On)
2351		unsigned16	0	0	1			Enable(1)/disable(0) the module
2352	Sample/Zero valve and Reference Mode	unsigned16	0	0	4			iO Reference Mode [48iQTL only]
2451		string	0.0.0.0	7	15	characters		Dynamic IP Address
2459		string	0.0.0.0	7	15	characters		Dynamic Subnet Mask
2467		string	0.0.0.0	7	15	characters		Dynamic Gateway Address
2475		string	0:00:00:00	17	17	characters		Wired MAC Address
2484	Ethernet Configuration Alarm	unsigned16	0	0	1			Ethernet Configuration Alarm Flag
2485	Ethernet IP Address Configuration Alarm	unsigned16	0	0	1			Ethernet IP Address Configuration Alarm Flag
2486	Ethernet Subnet Mask Configuration Alarm	unsigned16	0	0	1			Ethernet Subnet Mask Configuration Alarm Flag
2487	Ethernet Gateway Configuration Alarm	unsigned16	0	0	1			Ethernet Gateway Configuration Alarm Flag
2488	Ethernet DNS Configuration Alarm	unsigned16	0	0	1			Ethernet DNS Configuration Alarm Flag
2489	Ethernet DNS Configuration Alarm	unsigned16	0	0	1			Ethernet DNS Configuration Alarm Flag
5158		string	0.0.0.0	7	15	characters		Wired DNS Address
5166		string	0.0.0.0	7	15	characters		Wired DNS Address 2
5174	Ethernet Configuration commit	unsigned16	0	0	1			Ethernet Configuration commit
5182		unsigned16	0	0	2			Date Format: 0=MM/DD/YYYY (US) 1=DD/MM/YYYY (EU)2=YYYY-MM-DD (ISO 8601)
5183		unsigned16	50	5	100	%		Screen Brightness
5184		unsigned16	0	0	1			Sleep Enable Status
5185		unsigned16	5	1	720	minutes		Sleep Timeout value in minutes
5186		unsigned16	0	0	23			Update clock time: Hours - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5187		unsigned16	0	0	59			Update clock time: Minutes - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5188		unsigned16	0	0	59			Update clock time: Seconds - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5189		unsigned16	1	1	12			Update clock time: Month - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5190		unsigned16	1	1	31			Update clock time: Day - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5191		unsigned16	2001	2001	2038			Update clock time: Year - set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5192		string	0	0	32	characters		Timezone Code (Hours from UTC):DLW+12NST+11HST+10YST+9PST+8PST+8PDTMS T+7MST+7MDTCSST+6CST+6CDT EST+5EST+5EDTCOT+4ART+3GST+2CVT+1UTC0 CET-1CET-2BST-3DLT-4CET-5FOX-6GLF-7CCT-8JST-9GST-10LMA-11DLE-12

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
5208		unsigned16	0	0	3			Allows setting of time/date: set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5209		unsigned16	0	0	2			Signal to set time/date
5210		unsigned32	0			seconds		Seconds from 1/1/1970
5212		unsigned16	1	0	2			Enable Time Server
5213		string		0	30			Set Time Server
5228		unsigned16	0					User Data Logging Treatment mode to use: Average=0 Current=1 Max=2 Min=3
5229		unsigned16	0					Data Logging database is ready
5230		string	0	0	2	characters		The number of digits to display after the decimal for concentration data
5231	DF Low Range Enable	unsigned16	0	0	1			Dynamic Filter Low Range Enable (1=On/0=Off)
5232	DF High Range Enable	unsigned16	0	0	1			Dynamic Filter High Range Enable (1=On/0=Off)
5233	Cal Background	unsigned16	0	0	1			Digital IO for Auto Background Calibration
5234	Cal Lo Span	unsigned16	0	0	1			Digital IO for Low Range Auto Span Calibration
5235	Cal Hi Span	unsigned16	0	0	1			Digital IO for High Range Auto Span Calibration
5236		unsigned16	0	0	2			Commit user time change: set 5208 to 2(GUI) or 3(Modbus) - set desired time registers - set 5236 to 1 - set 5208 to 0
5237		unsigned16	0	0	1			If any pop up is open on the GUI the register will read 1. To close the dialog set this register to 0.
5500	Digital IO Module Enable	unsigned16	0	0	1			Enable/disable the Digital IO module
5600		unsigned16	1	0	1			Allow Analog Outputs to go over or under range: 0 = Disable 1 = Enable
5601	Analog IO Module Enable	unsigned16	0	0	1			Enable/Disable the Analog IO module
5602		float	0					Voltage Output Minimum 1
5604		float	0					Voltage Output Minimum 2
5606		float	0					Voltage Output Minimum 3
5608		float	0					Voltage Output Minimum 4
5610		float	0					Voltage Output Minimum 5
5612		float	0					Voltage Output Minimum 6
5614		float	100					Voltage Output Maximum 1
5616		float	100					Voltage Output Maximum 2
5618		float	100					Voltage Output Maximum 3
5620		float	100					Voltage Output Maximum 4
5622		float	100					Voltage Output Maximum 5
5624		float	100					Voltage Output Maximum 6
5626		float	0					Current Output Minimum 1
5628		float	0					Current Output Minimum 2
5630		float	0					Current Output Minimum 3
5632		float	0					Current Output Minimum 4
5634		float	0					Current Output Minimum 5
5636		float	0					Current Output Minimum 6
5638		float	0					Current Output Maximum 1
5640		float	0					Current Output Maximum 2
5642		float	0					Current Output Maximum 3
5644		float	0					Current Output Maximum 4
5646		float	0					Current Output Maximum 5
5648		float	0					Current Output Maximum 6
5683		unsigned32	1	1	255			Serial Instrument ID
5700		unsigned16	1	0	1			Enable/Disable the Flow/Pressure module
6000	Purge Mode	unsigned16	0	0	1			Purge Mode
6001	Zero Mode	unsigned16	0	0	1			Zero Mode
6002	Span Mode	unsigned16	0	0	1			Span Mode
6003	Sample Mode	unsigned16	1	0	1			Sample Mode
6004	Ext Span Mode	unsigned16	0	0	1			Ext Span Mode (Optional)

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
6005		unsigned16	0	0	1			iO Reference Mode [48iQTL only]
6006	Gas Mode	unsigned16	0	0	9			Gas Mode: SAMPLE=0; ZERO=1; SPAN=2; PURGE=3; AUTO ZERO=4; AUTO SPAN=5; AUTO PURGE=6; EXTSPAN=7; iO REFERENCE=8; WARMUP=9; NOTE: Scheduled calibrations should not be set via Modbus (AUTO ZERO; AUTO SPAN ; AUTO PURGE)
6100	Dilution Module Enable	unsigned16	1	0	1			Enable/disable the Dilution module
6101		float	1	1	500			Dilution ratio
6200	Perm Oven Enable	unsigned16	0	0	1			Enable/disable the module
6201		string	--	0	12			Permeation Tube Gas Name [if Perm Oven installed]
6207		float	190	1	100000			Permeation Tube Rate [if Perm Oven installed]
6209		float	0.382	0.0001	9.999			Permeation Tube Molar Constant [if Perm Oven installed]
6600	Gas Units	string	ppb	0	6			Gas Units
6606		unsigned16	1	0	1			Single Range Mode Request
6607		unsigned16	0	0	1			Dual Range Mode Request
6608		unsigned16	0	0	1			Auto Range Mode Request
6609	Averaging Time (sec)	unsigned16	300	1	300	sec		Single/Low Range Averaging Time (sec)
6610	High Averaging Time (sec)	unsigned16	300	1	300	sec		High Range Averaging Time (sec)
6611		unsigned16	0	0	99			Set to 1 to compute and save new calibration values
6612		float	0					Background Sepoint User Defined
6614		float	0					Single/Low Range Concentration User Defined
6616		float	0					High Range Concentration User Defined
6618	Single/Low Range User Coefficient Setpoint	float	1	0.5	2		3	Single/Low Range User Coefficient Setpoint
6620	High Range User Coefficient Setpoint	float	1	0.5	2		3	High Range User Coefficient Setpoint
6622	Logging Range Value	float				Basic Units		Logging Range Value
6624	Logging Range Value	float				Basic Units		Logging Range Value
6626	Range Mode Request	unsigned16	0	0	1			Extended Range Mode Request
6627	Pressure Alarm Minimum	float	600	250	1000	mmHg	1	Pressure Alarm Minimum
6629	Pressure Alarm Maximum	float	800	250	1000	mmHg	1	Pressure Alarm Maximum
6631	Flow Alarm Minimum	float	0.35	0	1.75	L/min	3	Flow Alarm Minimum
6633	Flow Alarm Maximum	float	1.5	0	1.75	L/min	3	Flow Alarm Maximum
6635	Instrument Temperature Alarm Minimum	float	0	-5	50	°C	1	Instrument Temperature Alarm Minimum
6637	Instrument Temperature Alarm Maximum	float	45	-5	50	°C	1	Instrument Temperature Alarm Maximum
6639		float	-999	-10000	5E+09			Concentration Alarm Minimum User Defined
6641		float	0	-10000	5E+09			Concentration Alarm Maximum User Defined
6900		unsigned16	0	0	1			Enable/disable the Communication module
7000		unsigned16	0	0	1			Enable/Disable the Predictive Diagnostics module
8000		unsigned16	0	0	7			Single/Low Range Multipoint Calibration Counter
8001		unsigned16	0	0	7			High Range Multipoint Calibration Counter
8002	Range Multipoint Calibration Coefficient 1	float	1				6	Single/Low Range Multipoint Calibration Coefficient 1

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
8004	High Range Multipoint Calibration Coefficient 1	float	1				6	High Range Multipoint Calibration Coefficient 1
8006	Range Multipoint Calibration Coefficient 2	float	0				6	Single/Low Range Multipoint Calibration Coefficient 2
8008	High Range Multipoint Calibration Coefficient 2	float	0				6	High Range Multipoint Calibration Coefficient 2
8010	Range Multipoint Calibration Coefficient 3	float	0				6	Single/Low Range Multipoint Calibration Coefficient 3
8012	High Range Multipoint Calibration Coefficient 3	float	0				6	High Range Multipoint Calibration Coefficient 3
8014		float				PPB		Single/Low Range Multipoint Cal Span Concentration 1(Basic Units ppb or ug/m3 for Logging and Protocols)
8016		float				PPB		High Range Multipoint Cal Span Concentration 1(Basic Units ppb or ug/m3 for Logging and Protocols)
8018		float				PPB		Single/Low Range Multipoint Cal Span Concentration 2(Basic Units ppb or ug/m3 for Logging and Protocols)
8020		float				PPB		High Range Multipoint Cal Span Concentration 2(Basic Units ppb or ug/m3 for Logging and Protocols)
8022		float				PPB		Single/Low Range Multipoint Cal Span Concentration 3(Basic Units ppb or ug/m3 for Logging and Protocols)
8024		float				PPB		High Range Multipoint Cal Span Concentration 3(Basic Units ppb or ug/m3 for Logging and Protocols)
8026		float	1	0.5	2		6	Single/Low Range Multipoint Cal Point 1 Coefficient
8028		float	1	0.5	2		6	High Range Multipoint Cal Point 1 Coefficient
8030		float	1	0.5	2		6	Single/Low Range Multipoint Cal Point 2 Coefficient
8032		float	1	0.5	2		6	High Range Multipoint Cal Point 2 Coefficient
8034		float	1	0.5	2		6	Single/Low Range Multipoint Cal Point 3 Coefficient
8036		float	1	0.5	2		6	High Range Multipoint Cal Point 3 Coefficient
8038		float						Single/Low Range Multipoint Cal Point 1 VarX
8040		float						High Range Multipoint Cal Point 1 VarX
8042		float						Single/Low Range Multipoint Cal Point 2 VarX
8044		float						High Range Multipoint Cal Point 2 VarX
8046		float						Single/Low Range Multipoint Cal Point 3 VarX
8048		float						High Range Multipoint Cal Point 3 VarX

Register	Data Logging/Streaming Variables	Type	Default	Min	Max	Units	Precision	Description
8050		unsigned16	0	0	65535			remote input cal manager Directions to perform Calibrations using Modbus:Manual Bkg: set modbus register 8051 to desired background value in Base Gas Units (PPB or ug/m3) (to see Adjusted Conc value read 925 register); set modbus register 8050 to 1.Auto Bkg: set modbus register 8050 to 2;(To see Current Bkg read 933 and Calculated Bkg read 6612 in User Defined units)Manual Span or Manual Span Low: set modbus register 8051 to desired span coef value (to see Adjusted Conc read 925); set modbus register 8050 to 3.Manual Span High: set modbus register 8051 to desired span coef value (to see Adjusted High Range Conc read 927); set modbus register 8050 to 4.Auto Span or Auto Span Low: set modbus register 8051 to desired span conc in base gas units (PPB or ug/m3)(to see Current Span Coef read 929 and to see Calculated Span Coef read 6618); set modbus register 8050 to 5.Auto Span High: set modbus register 8051 to desired high span conc in base gas units (PPB or ug/m3)(to see Current High Range Conc read 13 to see Current High Range Span Coef read 931 and to see Calculated High Range Span Coef read 6620); set modbus register 8050 to 6.Manual Reset Defaults: set modbus register 8050 to 7.To see the new concentration value use register 7 single and low or 13 for high in BU units. To check what User Defined units are set to read register 6600.
8051	Target Calibration value	float	0	0	1E+07			Target calibration value
8054	User Defined	float	0	0	5E+09			User Defined
8056	User Defined	float	0	0	5E+09			User Defined
10000		string		0	50	characters		SMTP Server address for emails
10025		unsigned16	25	0				SMTP port for sending emails
10026		string		0	255	characters		E-mail From address for sending emails
10154		string		0	16	characters		E-mail password for sending emails
10162		string		0	255	characters		PCP email address
10290		string		0	255	characters		Contact Information: To: User email address
10418		string		0	255	characters		Contact Information: CC: User email address 1
10546		string		0	255	characters		Contact Information: CC: User email address 2
10674		string		0	255	characters		Contact Information: CC: User email address 3
10802		string		0	255	characters		Contact Information: CC: User email address 4
10930		string		0	255	characters		Contact Information: CC: User email address 5
11058		string		0	255	characters		Contact Information: CC: User email address 6
11186		string		0	255	characters		Contact Information: CC: User email address 7
11314		string		0	255	characters		Contact Information: CC: User email address 8
11442		string		0	255	characters		Contact Information: CC: User email address 9
11570		string		0	255	characters		Contact Information: CC: User email address 10

**USA**

27 Forge Parkway  
 Franklin, MA 02038  
 Ph: (508) 520-0430  
 Toll Free: (866) 282-0430  
 orders.aqi@thermofisher.com

Find out more at [thermofisher.com/iQSeries](http://thermofisher.com/iQSeries)